Models: 520, 720, 920, Allant, CrossRip, District, DS Series, Early, FX, Lync, Neko, Pure, Shift, Tandem, Verve, T80+, Lift+, Conduit+, Amsterdam+, Amsterdam, Cruiser, Kid's, Loft, Ticino, Townie, Townie GO!, Verve

		1	ci, Ria 3, Loit,		·			
	•	Rider w/ basic mechanical skills, tools, and knowledge						
	٧	Dealer/Experienced bicycle mechanic						
Service at the indicated distance or time - whichever is most	Months	Every	New Bike	3	6	9	12	24
appropriate for your riding conditions	Miles	Ride	1st	200	400	600	800	3000
appropriate for your maning containens	Hours	mac	Service	25	50	75	100	500
Annual Tune-up and Safety Inspection							٧	
Electronics								
Replace computer and sensor batteries							•	
Inspect electrical wires and connectors for damage			•		•		•	
Ride+								
Check for firmware updates			٧		٧		٧	
Brakes								
Test brake function		•						
Inspect brake pad and rim/disc for wear or contamination		•						
Inspect brake cables and housing for wear or damage		•						
Inspect brake hoses for damage		•						
Inspect brake mounting hardware			•		•		•	
Apply lubricant to brake lever pivots			•	•	•	•	•	
Lubricate brake pivots			•		•		•	
Bleed disc brake system							٧	
Drivetrain								
Inspect chain condition and clean/lube if necessary		•						
Inspect shift cables and housing for wear or damage		•						
Inspect the condition and operation of shift-levers and derailleurs		•						
Inspect the condition and operation of shift-levers and internal hub		•						
Inspect pedals for looseness or bearing play		•						
Clean/degrease drivetrain					٧		٧	
Inspect chain and sprockets for wear			٧		٧		٧	
Inspect derailleurs and lubricate pivots			٧		٧		٧	
Inspect derailleur hanger alignment and hardware			٧		٧		٧	
Inspect the crank/crankarms for damage or play			•		•		•	
Inspect the bottom bracket			٧		٧		٧	
Clean and inspect the bottom bracket cable guide					٧		٧	
Service pedals/grease threads							٧	
Service bottom bracket							٧	
Belt Drive								
Inspect condition of belt and cogs		•						
TAB								
Inspect belt tension/tensioner per TAB belt system manual					٧		٧	
Gates								
Inspect belt tension per Gates recommendations			•		٧		٧	
Continental								
Inspect belt tension per Continental recommendations			•		٧		٧	
Frame and Components								
Inspect frame and fork for damage		•						
Inspect stem, handlebar, seatpost, and saddle hardware		•						
Inspect stem, handlebar, seatpost, saddle, and headset adjustment		•						
Inspect reflectors, lights, and other safety equipment		•						
Inspect grips/bar tape. Clean or replace as necessary					•		•	
-1 O. Iba'		l		<u> </u>				

Inspect headset condition and adjustment			v		٧	
Inspect accessory hardware	V	•	•		•	
Clean and polish finish	+ •	•		•	•	
Service headset (additional care is required after riding in rain)		+	v	-	<b>√</b>	
			V		٧	
Clean/apply grease or carbon paste to stem and seatpost					V	
Suspension Fork  Clean fork with mild soap and water, dry with soft towel						
Inspect upper tubes for scratches  •						
Lubricate dust seals and upper tubes  •						
	•		•		•	
Check air pressure/preload and sag  Disassemble and rebuild	+ •		<b>-</b>			
					٧	
Suntour						
Air			_,		-,	
Lubricate lower casting			٧		٧	
Change 80W oil in air chamber			٧		٧	
Coil						
Lubricate slider sleeve and wiper			٧		٧	
RST			_			
Replace dust seals			٧		٧	
Replace lubricant/grease			٧		٧	
Replace remote lockout cable	_				٧	
SPA						
Inspect fork function					٧	
Bontrager Satellite Elite						
Inspect fork function					٧	
Wheels						
Semi-Annual Wheel Tune-up and Safety Inspection			٧		٧	
Verify tightness of wheel quick-release skewers  •						
Inspect spokes for damage •						
Inspect rims for wear or damage •						
Verify that wheels are centered and spin freely without play  •						
Inspect spoke tension and wheel true	٧		٧		٧	
Inspect wheel bearing condition and adjustment	٧		٧		٧	
Clean and lubricate quick-release skewers/axles					•	
Inspect hubs and service freehub					٧	
Shimano Internal hub						
Change hub oil				٧		٧
Tires						
Inspect tire pressures and properly inflate if necessary •						
Inspect tread and sidewall for damage or wear •						
Measure tread depth to gauge wear			٧		٧	
Recharge TLR sealant and clean valve (if set up tubeless)		•	•	•	•	