



▲ WARNING: Cycling can be dangerous. Bicycle products should be installed and serviced by a professional mechanic. Never modify your bicycle or accessories. Read and follow all product instructions and warnings including information on the manufacturer's website. Inspect your bicycle before every use. Always wear a helmet.

Always check air pressure before riding. For more product and safety information go to www.teravail.com

Installing a Tire and Tube

1. Inspect rim and rim tape. Clear debris from inner tire surface of rim. Replace rim and rim tape if damaged. Ensure all spoke holes and nipples are covered.
2. Install one side of the tire onto the rim.
3. Inflate tube slightly so that it is round but smaller than the tire.
4. Insert tube valve into the valve hole on the rim. Install lock nut onto the valve, leave loose against the rim.
5. Push tube into the partially installed tire. Ensure the tube is not twisted. Valve should be perpendicular to the rim.
6. Carefully push the loose tire sidewall over the rim lip, starting opposite of the valve. Do not pinch tube between the rim and tire. Work around the tire until the tire is fully installed. If unable to install the tire by hand, use a tire lever to gain leverage. Do not to pinch the tube or damage the rim with a tire lever.
Note: Check with rim manufacturer before using tire levers.
7. Visually inspect the space between the tire sidewall and both sides of the rim by squeezing the tire. Make sure the tube is not pinched between the rim and tire.
8. Inflate tube so that it is pressing against the tire in all locations and then repeat Step 7.
9. Continue to inflate tube slowly. If the tire is migrating off of the rim, stop, deflate the tube, and repeat. Inflate the tube until the tire bead is fully seated on the rim.
10. Adjust pressure to the pressure limit indicated on the tube or the tire, whichever is less.
11. Close air valve, finger tighten lock nut against the rim, and install valve cap.
12. Inspect the tire for any bulges, delamination or obvious defects.

Limited Warranty

This product is warranted against defects in materials and workmanship for 2 years from the date of retail purchase of the product, subject to the limitations detailed below. Save your dated receipt for proof of purchase.

This warranty does NOT cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Installation of components, parts or accessories not originally intended for or compatible with product as sold
- Damage or deterioration to the paint, surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

This limited warranty is expressly limited to the repair or replacement of the original product, at the option of Teravail, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Teravail product and is not transferable. This warranty applies only to products purchased through an authorized dealer or distributor. In no event shall Teravail be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to Teravail products except as set forth herein.

This warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This warranty does not affect your statutory rights.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Warranty Registration: Proof of purchase is required before a warranty claim is processed. Teravail therefore strongly encourages warranty registration at teravail.com. Failure to register will not affect consumer rights under the limited warranty stated above, so long as the consumer can show in a reasonable manner proof of original ownership and the date the Teravail product was purchased. If you have any questions contact warranty@teravail.com.

Submitting a Claim can be made anywhere Teravail products are sold. When in doubt, contact your local shop. Please provide details about what happened including but not limited to other components used in conjunction with the alleged defective Teravail part.

NOTE: The term of the Warranty is not a guarantee of the product's useful life. Product life is influenced by how the product is used, stored, and maintained over time. The Warranty is not meant to suggest the product cannot be broken or that the product will last forever. The Warranty only means the product is covered subject to the terms of the Warranty.