

**TREK****Kid's Road & City**

Service at the indicated distance or time - whichever is most appropriate for your riding conditions	Months	Every Ride	New Bike 1st Service	3	6	9	12
	Miles			200	400	600	800
	Hours			25	50	75	100
<b>Annual Tune-up and Safety Inspection</b>							√
<b>Electronics</b>							
Replace computer and sensor batteries							•
<b>Trailer Bike</b>							
Inspect tow arm and hitch hardware							
<b>Brakes</b>							
Test brake function		•					
Inspect brake pad and rim wear		•					
Inspect brake cables and housing for wear or damage		•					
Inspect brake mounting hardware			•	•			•
Apply lubricant to brake lever pivots			•	•	•		•
Lubricate brake pivots			•	•			•
<b>Drivetrain</b>							
Inspect chain condition and clean/lube if necessary		•					
Inspect shift cables and housing for wear or damage		•					
Inspect the condition and operation of shift-levers and derailleurs		•					
Clean/degrease drivetrain					√		√
Inspect chain and sprockets for wear			√		√		√
Inspect derailleurs and lubricate pivots			√		√		√
Inspect derailleur hanger alignment and hardware			√		√		√
Inspect the crank/crankarms for damage or play			√		√		√
Clean and inspect the bottom bracket cable guide			√		√		√
Inspect the bottom bracket			√		√		√
Inspect pedals for looseness or bearing play			√		√		√
Service pedals/grease threads							√
Service bottom bracket							√
<b>Frame and Components</b>							
Inspect frame and fork for damage		•					
Inspect stem, handlebar, seatpost, and saddle hardware		•					
Inspect stem, handlebar, seatpost, saddle, and headset adjustment		•					
Inspect reflectors, lights, and other safety equipment		•					
Inspect grips					•		•
Inspect headset condition and adjustment			√		√		√
Inspect accessory hardware			•		•		•
Clean and polish finish				•	•	•	•
Service headset							√
Clean/apply grease or carbon paste to stem and seatpost							√
<b>Trailer Bike</b>							
Inspect tow arm and hitch hardware		•					
<b>Wheels</b>							
<b>Semi-Annual Wheel Tune-up and Safety Inspection</b>					√		√
Verify tightness of wheel quick-release skewers		•					
Inspect spokes for damage		•					
Inspect rims for wear or damage		•					
Verify that wheels are centered and spin freely without play		•					
Inspect spoke tension and wheel true			√		√		√
Inspect wheel bearing condition and adjustment			√		√		√
Clean and lubricate quick-release skewers/axles							•
Inspect hubs and service freehub							√

Tires						
Inspect tire pressures and properly inflate if necessary	•					
Inspect tread and sidewall for damage or wear	•					
Recharge TLR sealant and clean valve (if set up tubeless)			•	•	•	•