

City

Models: 520, 720, 920, Allant, CrossRip, District, DS Series, Early, FX, Lync, Neko, Pure, Shift, Tandem, Verve, T80+, Lift+, Conduit+, Amsterdam+, Amsterdam, Cruiser, Kid's, Loft, Ticino, Townie, Townie GOI, Verve

	•	Rider w/ basic mechanical skills, tools, and knowledge						
	√	Dealer/Experienced bicycle mechanic						
Service at the indicated distance or time - whichever is most appropriate for your riding conditions	Months	Every Ride	New Bike 1st Service	3	6	9	12	24
	Miles			200	400	600	800	3000
	Hours			25	50	75	100	500
Annual Tune-up and Safety Inspection								
Electronics								
Replace computer and sensor batteries								•
Inspect electrical wires and connectors for damage			•		•			•
Ride+								
Check for firmware updates			√		√			√
Brakes								
Test brake function	•							
Inspect brake pad and rim/disc for wear or contamination	•							
Inspect brake cables and housing for wear or damage	•							
Inspect brake hoses for damage	•							
Inspect brake mounting hardware			•		•			•
Apply lubricant to brake lever pivots			•	•	•	•		•
Lubricate brake pivots			•		•			•
Bleed disc brake system								√
Drivetrain								
Inspect chain condition and clean/lube if necessary	•							
Inspect shift cables and housing for wear or damage	•							
Inspect the condition and operation of shift-levers and derailleurs	•							
Inspect the condition and operation of shift-levers and internal hub	•							
Inspect pedals for looseness or bearing play	•							
Clean/degrease drivetrain					√			√
Inspect chain and sprockets for wear			√		√			√
Inspect derailleurs and lubricate pivots			√		√			√
Inspect derailleur hanger alignment and hardware			√		√			√
Inspect the crank/crankarms for damage or play			•		•			•
Inspect the bottom bracket			√		√			√
Clean and inspect the bottom bracket cable guide					√			√
Service pedals/grease threads								√
Service bottom bracket								√
Belt Drive								
Inspect condition of belt and cogs	•							
TAB								
Inspect belt tension/tensioner per TAB belt system manual					√			√
Gates								
Inspect belt tension per Gates recommendations			•		√			√
Continental								
Inspect belt tension per Continental recommendations			•		√			√
Frame and Components								
Inspect frame and fork for damage	•							
Inspect stem, handlebar, seatpost, and saddle hardware	•							
Inspect stem, handlebar, seatpost, saddle, and headset adjustment	•							
Inspect reflectors, lights, and other safety equipment	•							
Inspect grips/bar tape. Clean or replace as necessary					•			•
Inspect headset condition and adjustment			√		√			√
Inspect accessory hardware			•		•	•		•
Clean and polish finish					•	•		•
Service headset (additional care is required after riding in rain)					√			√
Clean/apply grease or carbon paste to stem and seatpost								√
Suspension Fork								
Clean fork with mild soap and water, dry with soft towel	•							
Inspect upper tubes for scratches	•							
Lubricate dust seals and upper tubes	•							
Check air pressure/preload and sag			•		•			•
Disassemble and rebuild								√
Suntour								
Air								
Lubricate lower casting					√			√
Change 80W oil in air chamber					√			√
Coil								
Lubricate slider sleeve and wiper					√			√
RST								
Replace dust seals					√			√
Replace lubricant/grease					√			√
Replace remote lockout cable								√
SPA								
Inspect fork function								√
Bontrager Satellite Elite								
Inspect fork function								√
Wheels								
Semi-Annual Wheel Tune-up and Safety Inspection								
Verify tightness of wheel quick-release skewers	•							
Inspect spokes for damage	•							
Inspect rims for wear or damage	•							
Verify that wheels are centered and spin freely without play	•							
Inspect spoke tension and wheel true			√		√			√
Inspect wheel bearing condition and adjustment			√		√			√
Clean and lubricate quick-release skewers/axles								•
Inspect hubs and service freehub								√
Shimano Internal hub								
Change hub oil							√	√
Tires								
Inspect tire pressures and properly inflate if necessary	•							
Inspect tread and sidewall for damage or wear	•							
Measure tread depth to gauge wear					√			√
Recharge TLR sealant and clean valve (if set up tubeless)					•	•	•	•